


Universal Sensor 61005/30



- 1) LCD-skjerm
- 2) Tilbake knapp
- 3) Opp knapp
- 4) RJ11 sokkel
- 5) 3,5 mm jack inngang
- 6) Ned knapp
- 7) Reed Switch
- 8) Velg knapp
- 9) Rød LED

Velkommen til Universalsensoren

For å starte, slå på universalsensoren ved å trykke og holde inne "Velg" og "Opp" knappen i noen sekunder. Les installasjonsmanualen for du programmerer Universalsensoren.

For instruksjoner og sikkerhetsinformasjon, se Universalsensorens installasjonsmanual.

Parameterere for radiosender

Radiofrekvens: 869.2125MHz

Stråling: Mindre enn 1 milliwatts

Bruksområde: Europa

Miljøgruppe: Gruppe II – Hovedsakelig innendørs

Samsvarserklæring

Tunstall erklærer at radioutstyret er i samsvar med direktiv 2014/53/EU. Samsvarserklæringen er tilgjengelig her:

uk.tunstall.com/approvals

Tunstall



www.tunstall.com

Our policy of continual development means that product specification and appearance may change without notice.

© 2018 Tunstall Group Ltd.

® TUNSTALL is a registered trademark

A member of the Tunstall Healthcare Group

Tunstall Group Limited, Whitley Lodge, Whitley Bridge, Yorkshire DN14 0HR