



UNDERSTELL SOM PASSER TIL HM MYKSTØP

Guppy G2 ▶



Str. 1

Guppy G2 str. 1 manuell
Art. nr.: 386601K
HMS. nr.: 333527

Str. 2

Guppy G2 str. 2 manuell
Art. nr.: 386602K
HMS. nr.: 333528

Str. 3

Guppy G2 str. 3 manuell
Art. nr.: 386610K
HMS. nr.: 333529

Guppy G2 str. 3 bred
Art. nr.: 386615K
HMS. nr.: 333537

Guppy G2 str. 3 bred/lav
Art. nr.: 386755K
HMS. nr.: 301455

Flipper G2 ▶



Manuell



El./man. tilt



El./el. tilt

Str. 2

Flipper G2 str. 2 manuell
Art. nr.: 844381K
HMS. nr.: 333521

Flipper G2 str. 2 el./man. tilt
Art. nr.: 844382K
HMS. nr.: 333523

Flipper G2 str. 2 el./el. tilt
Art. nr.: 844383K
HMS. nr.: 333525

Str. 3

Flipper G2 str. 3 manuell
Art. nr.: 844384K
HMS. nr.: 333522

Flipper G2 str. 3 el./man. tilt
Art. nr.: 844385K
HMS. nr.: 333524

Flipper G2 str. 3 el./el. tilt
Art. nr.: 844386K
HMS. nr.: 333526

Str. 4

Flipper G2 str. 4 el./el. tilt
Art. nr.: 844398K
HMS. nr.: 333536

Flipper G2 str. 4 el./man. tilt
Art. nr.: 844397K
HMS. nr.: 333535

Flipper Flex G2 ►



Flipper Flex G2 manuell
Art. nr.: 844440K
HMS. nr.: 333530

Flipper Flex G2 el.
Art. nr.: 844441K
HMS. nr.: 333531

Flipper Flex el./el. tilt
Art. nr.: 844446K
HMS. nr.: 333532

Zitzi Seabass G2 ►



Str. 1

Zitzi Seabass G2 str. 1 manuell
Art. nr.: 386291K
HMS. nr.: 333533

Str. 2

Zitzi Seabass G2 str. 2 manuell
Art. nr.: 386292K
HMS. nr.: 333538

Zitzi Seabass G2 Lav str. 1 manuell
Art. nr.: 386296K
HMS. nr.: 333540

Zitzi Seabass G2 Lav str. 2 manuell
Art. nr.: 386297K
HMS. nr.: 333541

Str. 3

Zitzi Seabass G2 str. 3 manuell
Art. nr.: 386293K
HMS. nr.: 333539

Zitzi Seabass G2 Lav str. 3 manuell
Art. nr.: 386298K
HMS. nr.: 333542
