












Minitech AS

Batterikompatibilitetsoversikt

2026



Prod.nr.	Produkt	Størrelse											
			3.6V/2.35Ah høyre, kort kabel HMS-nr. 252951	3.6V/2.35Ah venstre, kort kabel HMS-nr. 252952	3.6V/2.35Ah rett, lang kabel HMS-nr. 309444	3.6V/6.4Ah høyre, kort kabel HMS-nr. 252955	3.6V/6.4Ah venstre, kort kabel HMS-nr. 252956	3.6V/6.4Ah rett, lang kabel HMS-nr. 309445	3.6V/9.6Ah rett, lang kabel HMS-nr. 309446	7.2V/3.2Ah høyre, kort kabel HMS-nr. 252961	7.2V/3.2Ah venstre, kort kabel HMS-nr. 252962	7.2V/3.2Ah rett, lang kabel HMS-nr. 309447	7.2V/6.4Ah rett, lang kabel HMS-nr. 309448
400112	Minitech varmevott Multishell 3.6V/2.35Ah	6-8	✓	✓		✓*	✓*	✓*	✓*				
400152	Minitech varmevott Multishell 7.2V/3.2Ah	9-12								✓	✓		✓*
400112-Z	Minitech varmevott Multishell Zip 3.6V/2.35Ah	6-8	✓	✓		✓*	✓*	✓*	✓*		✓		
400152-Z	Minitech varmevott Multishell Zip 7.2V/3.2Ah	9-13								✓			✓*
200212-SR	Minitech varmevott Fjellvott Sr. 3.6V/2.35Ah	6-8	✓	✓		✓*	✓*	✓*	✓*				
200252-SR	Minitech varmevott Fjellvott Sr. 7.2V/3.2Ah	9-12								✓	✓		✓*
400412	Minitech varmevott Heli Ski 3.6V/2.35Ah	6-8	✓	✓		✓*	✓*	✓*	✓*				
400452	Minitech varmevott Heli Ski 7.2V/3.2Ah	9-12								✓	✓		✓*
410212	Minitech varnehanske Roller 3.6V/2.35Ah	6-8	✓	✓		✓*	✓*	✓*	✓*				
410252	Minitech varnehanske Roller 7.2V/3.2Ah	9-12								✓	✓		✓*
410412	Minitech varnehanske Tolga 3.6V/2.35Ah	6-8	✓	✓		✓*	✓*	✓*	✓*				
410452	Minitech varnehanske Tolga 7.2V/3.2Ah	9-12								✓	✓		✓*
410312	Minitech varnehanske Heli Ski Finger 3.6V/2.35Ah	6-8	✓	✓		✓*	✓*	✓*	✓*				
410352	Minitech varnehanske Heli Ski Finger 7.2V/3.2Ah	9-13								✓	✓		✓*
410112-F	Minitech varnehanske Tallberg Dame 3.6V/2.35Ah	6-9	✓	✓		✓*	✓*	✓*	✓*				
410112-M	Minitech varnehanske Tallberg Herre 3.6V/2.35Ah	7-8	✓	✓		✓*	✓*	✓*	✓*				
410152-M	Minitech varnehanske Tallberg Herre 7.2V/3.2Ah	9-12								✓	✓		✓*
410752	Minitech innerhanske Handy Aktiv 7.2V/3.2Ah	Alle								✓	✓		✓*
200312	Minitech varmevott Baby Zip 3.6V/2.35Ah	Alle	✓	✓		✓*	✓*	✓*	✓*				
200212-JR	Minitech varmevott Fjellvott Jr. 3.6V/2.35Ah	Alle	✓	✓		✓*	✓*	✓*	✓*				
200712	Minitech varmevott Junior Zip 3.6V/2.35Ah	Alle	✓	✓		✓*	✓*	✓*	✓*				
200112	Minitech varmevott Goretex Jr. 3.6V/2.35Ah	Alle	✓	✓		✓*	✓*	✓*	✓*				
200712	Minitech varmevott Junior Zip 3.6V/2.35Ah	Alle	✓	✓		✓*	✓*	✓*	✓*				
200412	Minitech varmevott Heli Ski Jr. 3.6V/2.35Ah	Alle	✓	✓		✓*	✓*	✓*	✓*				
210112	Minitech varnehanske Prima 3.6V/2.35Ah	Alle	✓	✓		✓*	✓*	✓*	✓*				
210312	Minitech varnehanske Trysil 3.6V/2.35Ah	Alle	✓	✓		✓*	✓*	✓*	✓*				
440112	Minitech arbeidshanske Herkules 3.6V/2.35Ah	6-8	✓	✓		✓*	✓*	✓*	✓*				
440152	Minitech arbeidshanske Herkules 7.2V/3.2Ah	9-13								✓	✓		✓*
440212	Minitech arbeidshanske Monty 3.6V/2.35Ah	8-8	✓	✓		✓*	✓*	✓*	✓*				
440252	Minitech arbeidshanske Monty 7.2V/3.2Ah	19-12								✓	✓		✓*
630112	Minitech joystickvott Splitt 3.6V/2.35Ah	5-8	✓	✓		✓*	✓*	✓*	✓*				
630152	Minitech joystickvott Splitt 7.2V/3.2Ah	9-13								✓	✓		✓*
630212	Minitech joystickvott Splitt (uten splitt/åpning) 3.6V/2.35Ah	5-8	✓	✓		✓*	✓*	✓*	✓*				
630252	Minitech joystickvott Splitt (uten splitt/åpning) 7.2V/3.2Ah	9-13										✓	✓*
420112	Minitech varmesokker Ull 3.6V/2.35Ah	36/39			✓	✓*	✓*	✓*	✓*				
420152	Minitech varmesokker Ull 7.2V/3.2Ah	40/44-45/48										✓	✓*
420212	Minitech varmesokker Ull Tykk 3.6V/2.35Ah	36/39			✓	✓*	✓*	✓*	✓*				
420252	Minitech varmesokker Ull Tykk 7.2V/3.2Ah	40/44-45/48										✓	✓*
420352	Minitech varmeknestrømper Kne Tykk 7.2V/3.2Ah	Alle										✓	✓*
220112	Minitech varmesokker Mico 3.6V/2.35Ah	Alle			✓	✓*	✓*	✓*	✓*				
220212	Minitech varmeknestrømper Seger 3.6V/2.35Ah	Alle			✓	✓*	✓*	✓*	✓*				
600112	Minitech varmesåler Bowie 3.6V/2.35Ah	20/21-41			✓	✓*	✓*	✓*	✓*				
600152	Minitech varmesåler Bowie 7.2V/3.2Ah	42-48										✓	✓*
620112	Minitech termosokker Termo 3.6V/2.35Ah	19/21-36/69	✓	✓		✓*	✓*	✓*	✓*				
620152	Minitech termosokker Termo 7.2V/3.2Ah	40/44-45/48								✓	✓		✓*

Symbol Informasjon:

✓ = Produktserien er designet for bruk med denne batteritypen.

✓* = Produktserien er kompatibel med denne batteritypen men krever enten tilpasning av batterilommer eller at batteriet plasseres på et annet sted en standard.

= Produktserien er ikke kompatibel med denne batteritypen.