



HMS nr.: 328269 / Lev.art.nr.:606600

ARM portable alerter button

ARM portable alerter button sender varsel til FlexiBlink-mottakere. ARM er en kombinert sender og mottaker og den vibrerer når den tar imot signaler fra FlexiBlink-systemet. Som standard varsler ARM Assistanse ønskes.

Brukes ofte sammen med følgende produkter:

Arm portable alerter button HMS nr.: 328269 	Noa no touch button HMS nr.: 328271 
Felix doorbell push button HMS nr.: 328247 	IRIS Alerter HMS nr.: 328250 
Alma alerter HMS nr.: 328251 	Ella portable call button HMS nr.: 328268 
Nora alert watch HMS nr.: 328248 	Junior portable alerter HMS nr.: 328249 