

# UNDERSTELL SOM PASSER TIL HM MYKSTØP

HM Mykstøp



Seabass str. 1



**Seabass G2 str. 1 manuell**

Art. nr.: 386791  
HMS. nr.: 293470

**Seabass G2 Lav str. 1 manuell**

Art. nr.: 386796  
HMS. nr.: 293473

Seabass str. 2



**Seabass G2 str. 2 manuell**

Art. nr.: 386792  
HMS. nr.: 293471

**Seabass G2 Lav str. 2 manuell**

Art. nr.: 386797  
HMS. nr.: 293474

Seabass str. 3



**Seabass G2 str. 3 manuell**

Art. nr.: 386793  
HMS. nr.: 293472

**Seabass G2 Lav str. 3 manuell**

Art. nr.: 386798  
HMS. nr.: 293475

## Guppy G2 str. 1



### Guppy G2 str. 1 manuell

Art. nr.: 386601  
HMS. nr.: 288376

## Flipper G2 str. 2



### Flipper G2 str. 2 manuell

Art. nr.: 844303K  
HMS. nr.: 293466

### Flipper G2 str. 2 El./man tilt

Art. nr.: 844304K  
HMS. nr.: 293462

### Flipper G2 str. 2 El./el. tilt

Art. nr.: 844320K  
HMS. nr.: 293464

## Guppy G2 str. 2



### Guppy G2 str. 2 manuell

Art. nr.: 386606  
HMS. nr.: 288377

## Flipper G2 str. 3



### Flipper G2 str. 3 manuell

Art. nr.: 844305K  
HMS. nr.: 293467

### Flipper G2 str. 3 El./man tilt

Art. nr.: 844306K  
HMS. nr.: 293463

## Guppy G2 str. 3



### Guppy G2 str. 3 manuell

Art. nr.: 386610  
HMS. nr.: 293468

## Flipper G2 str. 4



### Flipper G2 str. 4 El./man. tilt

Art. nr.: 844308  
HMS. nr.: 288374

### Flipper G2 str. 4 El./el tilt

Art. nr.: 844322  
HMS. nr.: 286574

## Guppy G2 str. 4



### Guppy G2 str. 4 manuell

Art. nr.: 386615  
HMS. nr.: 293469

## Flipper Flex G2



### Flipper Flex G2 manuell

Art. nr.: 844340  
HMS. nr.: 288368

### Flipper Flex G2 El.

Art. nr.: 844341  
HMS. nr.: 288369