


Features

The Rodger vibration watch is an innovative device for time-related activities.

- Up to 8 daily alarms
- Choice of vibration or sound alarm or both.
- 4 modes of operation: Time, Alarm, Countdown timer & Stopwatch.



How to set the correct time

- In TIME mode press [LIGHT/SET] and hold for about 2 seconds to select Seconds; seconds will start flashing.
- Press [START/STOP] to set the seconds to "00".
- Press [MODE/LOCK] to select Minutes; minutes will start flashing
- Press [START/STOP] until the correct minute is reached.
- Press [MODE/LOCK] to select Hours; hours will start flashing
- Press [START/STOP] until the correct hour is reached.
- Press [MODE/LOCK] to select Date; date will start flashing
- Press [START/STOP] until the correct date is reached.
- Press [MODE/LOCK] to select Months; months will start flashing
- Press [START/STOP] until the correct month is reached.
- Press [MODE/LOCK] to select Years; years will start flashing
- Press [START/STOP] until the correct year is reached.
- Press [LIGHT/SET] to leave the setting mode.

How to switch between 12 or 24 hour clock

- In TIME mode press [START/STOP] to switch between 12 or 24 hour clock.

How to view the current date

- In TIME mode press [DATE/RESET] to view the current date.

How to set the 8 individual alarm times

- Press [MODE/LOCK] until ALARM mode appears.
- Press [DATE/RESET] repeatedly to select the alarm you want to set (Alarm 1, 2, 3, 4, 5, 6, 7, 8). The selected alarm number will appear in the upper right of the LCD.
- Press [LIGHT/SET] and hold for about 2 seconds until the Hours start flashing.
- Press [START/STOP] until the correct hour is reached.
- Press [MODE/LOCK] to select Minutes.
- Press [START/STOP] until the correct minute is reached.
- Press [LIGHT/SET] to leave the setting mode.

How to turn the individual alarms on/off

- Press [MODE/LOCK] until ALARM mode appears.
- Press [DATE/RESET] repeatedly to select the alarm you want to turn on/off (Alarm 1, 2, 3, 4, 5, 6, 7, 8). The selected alarm number will appear in the upper right of the LCD.
- Press [DATE/RESET] and hold for about 2 seconds to turn the

selected alarm ON. The icon corresponding with the alarm number will appear on the LCD.

- Press [DATE/RESET] and hold for about 2 seconds again to turn the selected alarm OFF. The icon corresponding with the alarm number will disappear.

How to set the alarm type

- Press [MODE/LOCK] until ALARM mode appears.
- Repeat pressing [START/STOP] to rotate through the alarm type selection. When an alarm type is ON, its respective icon will be highlighted. Alarm type options are Beep sound ON, Vibration ON, Beep sound & Vibration ON, Beep sound & Vibration OFF.

How to use the countdown (timer mode)

To use the countdown timer you need to set the period of the day the countdown timer must count down, and the countdown time. When an alarm type is set in the ALARM mode and the actual time is within the countdown period of the day, the countdown timer repeats automatically after starting.

- Press [MODE/LOCK] until COUNTDOWN mode appears.
- Press [LIGHT/SET] and hold for about 2 seconds until start hour of daily countdown period start flashing.
- Press [START/STOP] to set start hour of daily countdown period.
- Press [MODE/LOCK] to select end hour of daily countdown period.
- Press [START/STOP] to set end hour of daily countdown period.
- Press [MODE/LOCK] to select the Hours of countdown time.
- Press [START/STOP] to set the hours of countdown time.
- Press [MODE/LOCK] to select the Minutes of countdown time.
- Press [START/STOP] to set the minutes of countdown time.
- Press [LIGHT/SET] to leave the setting mode.
- Press [START/STOP] to start the countdown timer.
- Press [START/STOP] again to stop countdown timer.

How to use the stopwatch

- Press [MODE/LOCK] until STOPWATCH mode appears.
- Press [START/STOP] to start the stopwatch.
- Press [START/STOP] to stop the stopwatch.
- Press [DATE/RESET] to reset the stopwatch.
- or -
- Press [START/STOP] again to resume the stopwatch.

To use and view split time

- Press [START/STOP] to start the stopwatch.
- Press [DATE/RESET] to interrupt and view split time (stopwatch resumes in background)
- Press [DATE/RESET] again to leave split time and resume measuring.
- or -
- Press [START/STOP] to stop stopwatch in background.
- Press [DATE/RESET] to view the end time of the stopwatch.
- Press [DATE/RESET] again to reset the stopwatch.

How to lock the buttons

- In TIME mode press [MODE/LOCK] and [DATE/RESET] simultaneously and hold for about 2 seconds to lock the buttons. The "LOCK"-indicator appears on the LCD.
- Press [MODE/LOCK] and [DATE/RESET] simultaneously and hold for about 2 seconds to unlock the buttons. The "LOCK"-indicator disappears from the LCD.

Battery information

The Rodger watch uses a standard 3 volt lithium CR2032 battery. Average battery life depends on how often the sound and vibration functions are used. To maintain water resistance, a qualified person should replace the battery.

Warranty

Rodger carries a one-year warranty, after receipt of the device by the purchaser, against manufacturer's defects and against breakage failure under normal use – at our discretion. This warranty does not cover normal wear and tear and aging, batteries, battery lids, glass bands or damage caused by water or misuse. Your watch is water resistant and will withstand accidental splashing or rain, but is not suitable for swimming, diving or showering. We shall not be liable for more or other than the aforesaid warranty obligations. This warranty is valid only if you are the first buyer and have the receipt. The warranty is not valid if the watch is not used in accordance with the instructions or if repairs to the device are made by third parties. Rodger reserves the right to change specifications and warranty without prior notice.

Disclaimer

Rodger does not accept any responsibility what so ever for any inconvenience or non-compliance for medication or any other reminder the watch may be used for.